


état
machine

ordres
utilisateur

action




ET

a	b	
0	0	0
0	1	0
1	0	0
1	1	1


OU

a	b	
0	0	0
0	1	1
1	0	1
1	1	1



Bas	Stop	$\overline{\text{Bas}}$	$\overline{\text{Stop}}$	S
0	0	1	1	1
0	1	1	0	0
1	0	0	1	0
1	1	0	0	0

ET ou





mode_manuel_3\$

```
if (digitalRead(bpBas) == 1) {  
  while ((digitalRead(rupteurBas) == 0) && (digitalRead(bpStop) == 0)) {  
    voletDescend();  
  }  
  voletStop();  
}  
else if (digitalRead(bpHaut) == 1) {  
  while ((digitalRead(rupteurHaut) == 0) && (digitalRead(bpStop) == 0)) {  
    voletMonte();  
  }  
  voletStop();  
}  
}
```

Handwritten red annotations: a large 'X' over the first '&&' and '88' with three horizontal lines below it.

Téléversement terminé

Le croquis utilise 1084 octets (3%) de l'espace de stockage de programmes. Le maximum est de 32256 octets.

Les variables globales utilisent 9 octets (0%) de mémoire dynamique, ce qui laisse 2047 octets disponibles. La limite est de 2048 octets.



